

RhinoClean™

AP200™ Screen Wash Degradent & Emulsion Remover

Description

- A water-soluble screen wash / Emulsion Remover designed to work quickly on Plastisol Inks.
- Ideal for efficient and expedient screen washing and reclaiming after the press run.
- Has a higher flash point than lacquer thinner, alcohols, ketones, etc.
- Biodegradable, non-toxic and environmentally friendly.

Directions

1. To remove ink and emulsion from screen images, apply AP200™ to both sides of screen and wipe the ink out of the screen. Option is to soak in a tank prior to removal with Pressure Washer.
2. With a high pressure washer, blast the stencil out of the mesh.
3. If any residue is left behind, use SW210 Ink Degradent haze remover, HR2800.

It is the responsibility of the screen printer to test the product; review the MSDS prior to use to evaluate whether or not the product is correct for the application intended.